


DIPSW3	Delete	Fn+Delete
0	Delete	BS
1	BS	BS



DIPSW4	DIPSW5	Alt	⬡	⬡	Alt
0	0	Alt	⬡	⬡	Alt
1	0	Alt	Fn	⬡	Alt
0	1	⬡	Alt	Alt	⬡
1	1	Fn	Alt	Alt	⬡

## 【Happy Hacking Keyboard Professional2】 ■英語配列モデル